



¹University of Central Florida, Orlando, Florida, USA

²Institute of Materials Research, German Aerospace Center, Cologne, Germany

Key Words: Thermal barrier coatings (TBCs); Calcium–magnesium–alumina–silicate (CMAS); Microstructure; Raman Spectroscopy

Motivation


- EB-PVD TBCs have been used to extend the life of jet engine turbine blades by protecting the substrate alloy from extreme thermal loads.
- EB-PVD TBCs have a strain-tolerant columnar microstructure with gaps that can be filled with CMAS oxides.
- Calcium-magnesium-aluminum-silicate (CMAS) or CaO, MgO, Al₂O₃, SiO₂, can deteriorate TBCs when this sand like material is ingested in the turbine.



- CMAS affects the life of TBCs due to thermochemical attack and thermomechanical effects
- Knowing the impact of CMAS interaction will help to quantify and mitigate their effects
- Raman spectroscopy has the potential to track phase changes from CMAS ingestion

Methods

- Raman spectroscopy is a nondestructive technique used to investigate the composition of materials scattering.




- The unique spectra caused by vibrational modes of bonds in the material can be linked to specific compositions: a chemical fingerprint

- Monoclinic Phase volume fraction can be calculated

$$f_m = \frac{(I_m^{182} + I_m^{191})}{((0.97) * (I_t^{148} + I_t^{263}) + I_m^{182} + I_m^{191})}$$

Sample YSZ-CMAS Spectra



Objectives

Collect Raman spectra to determine depth-resolved phase change with CMAS exposure.


Establish temperature dependency of phase change and ingress

Perform phase volume fraction calculations to quantify phase change

Experiment Setup

- 7YSZ was deposited on alumina substrates using EB-PVD
- CMAS is deposited in the center of the sample

label	Composition	Temperature (°C)	Total time (h)
B1	7YSZ+CMAS 1	1225	10
B2	7YSZ+CMAS 1	1250	1
B3	7YSZ+CMAS 1	1250	10



- Points of interest: Area outside CMAS infiltration (3), edge of CMAS infiltration (4) and CMAS center of infiltration (5).


Raman Spectra Collection Parameters

- 300RA WITec Confocal Raman microscope
- He:Ne 532 nm laser source
- Laser power: 22mW

CMAS 1 Composition (Melting Temperature 1230°C)

Oxide	CaO	MgO	Al ₂ O ₃	SiO ₂	FeO	TiO ₂
Wt%	22	8	18	40	10	2

Initial Observations




Sample B1, B2 and B3 showing the deposits after infiltration and heat treatment.


Preliminary qualitative analysis using an optical microscope at center point of infiltration (point 5):

- CMAS begins to melt, react, and infiltrate between 1230°C and 1250°C.
- B1 displays distinctive separation between CMAS grains and TBC surface: No indication of CMAS interaction with 7YSZ.
- Less CMAS was found on top of samples B2 and B3 compared to B1

Results as a Function of Location & Heat Treatment




- At point 3 there was no monoclinic phase signal found for any sample
- Monoclinic peaks were found for both B2 and B3 at CMAS-localized areas indicating a reaction has taken place
- B3 has the most dominant monoclinic peaks throughout as a result of longer heat treatment
- Point 5, shows less intense signals compared to point 4 as a result of the thick CMAS overlay



- B3 has PVF of 0.5 and 0.18 for points 4 and 5 respectively
- For both B2 and B3, point 4 shows greater monoclinic PVF indicating more desolation of the coating in this region
- Point 5 has reduced signal for all samples due to the CMAS overlay


2D Raman Imaging of B3 (1250°C, 10h)



- 7YSZ coating is most susceptible to monoclinic phase formation in the regions where the coating is in direct contact with the molten CMAS
- Monoclinic phase is reduced as depth into sample increases
- Presence of tetragonal is represented by areas with low intensity
- Raman can distinguish between monoclinic and tetragonal phases
- Raman mapping can substitute phase identification techniques such as TEX, XRD


Stress Measurements on B3

- Tracking the shift of the 640 cm⁻¹ Raman peak allows us to know about the type of stresses that are present within our TBC



Stress map at surface

- At the surface of the coating where there is more of the monoclinic phase, the stress map shows more tensile stress



Stress map 90 μm below surface

- Raman spectroscopy can also give us depth resolved measurements
- At a depth of 90 μm where the monoclinic phase is in smaller quantities, the stress is here is more compressive

Conclusions

- These results show that monoclinic peak identification is correlated with CMAS infiltration.
- Monoclinic phase volume fraction directly depends on CMAS infiltration temperature and reaction time.
- Raman imaging appears as an effective technique, not requiring any specific surface preparation, to track the 182 peak distribution in zirconia scales after oxidation due to CMAS.
- The method provides, in a single scan, not only structural and mechanical information, but also information about the corrosion process.
- Raman Imaging appears as an effective technique, not requiring any specific surface preparation, to track the 182 cm⁻¹ peak distribution in zirconia scales after oxidation due to CMAS

Acknowledgments

This material is based upon work supported by National Science Foundation grants DMR 1337758 and OISE 1460045 and by the German Aerospace Center (DLR).

Reference:
Bohorquez E., Sarley B., Hernandez J., Hoover R., Tetard L., Naraparaju R., Schulz U., Raghavan S., Investigation of the Effects of CMAS-infiltration in EB-PVD 7% Yttria-Stabilized Zirconia via Raman Spectroscopy. Extended abstract accepted for the 59th AIAA/ASCE/AHS/ASC Structural Dynamics, and Materials Conference, AIAA SciTech Forum, 8-12 January 2018, Orlando, FL.